




UP-TOWN RACK


DE MONTAGEANWEISUNG
GB ASSEMBLY INSTRUCTIONS
FR INSTRUCTIONS DE MONTAGE
IT ISTRUZIONI DI MONTAGGIO
NL MONTAGE HANDLEIDING
DK MONTERINGSVEJLEDNING
ES INSTRUCCIONES DE MONTAJE
SE MONTERINGSANVISNING
NO MONTERINGSANVISNING
FI ASENNUSOHJEET
PL INSTRUKCJA MONTAŻU
JP 装着方法




INHALT:
CONTENTS:
CONTENU:
CONTENUTO:
INHOUD:
INDHOLD:
CONTENIDO:
INNEHÅLL:
INNHOUD:
SISÄLLYS:
ZAWARTOŚĆ:
内容物表



18



19



20

OPEN

21

ADJUST





21a. EXAMPLE

21a.a. CLOSE

4x OPEN

ADJUST




4x CLOSE



21 b.a. CORRECT POSITION

21 b.b. WRONG POSITION

21 c. FIX



22


TEST

23

DIRECTION

24

UNFIX



25

26

CHECK FIXATION BEFORE EVERY RIDE

27

MAX. LOAD

