

VARIO 26L QL2.2
VARIO 20L QL2.2

- DE MONTAGEANWEISUNG
- GB ASSEMBLY INSTRUCTIONS
- FR INSTRUCTIONS DE MONTAGE
- IT ISTRUZIONI DI MONTAGGIO
- NL MONTAGE HANDLEIDING
- DK MONTERINGSVEJLEDNING
- ES INSTRUCCIONES DE MONTAJE
- SE MONTERINGSANVISNING
- NO MONTERINGSANVISNING
- FI ASENNUSOHJEET
- PL INSTRUKCJA MONTAŻU
- JP 装着方法



VIDEO




26 L



20 L



FOR 26L/20L VERSION



Sicherheitshinweis:


Bei wenig Beladung bitte den unteren Befestigungspunkt benutzen und fest abspannen.

Safety advice:



With little load, please use the lower attachment point and brace tight.




ONLY FOR 26L VERSION



✓ = O.K





✓ = O.K






✓ = O.K

QL2.2-SYSTEM

1. ADJUST HOOK TO CORRECT TUBE SIZE



10 - 16 mm } ✓
8 - 10 mm } = O.K.
<8 mm = ✗☠







2. ADJUST HOOK POSITION

2.1 AS WIDE AS POSSIBLE


OPTIONAL: WENN DER EXZENTERHEBEL ZU FEST ODER ZU LOCKER IST, KANN DER DRUCK IM GEÖFFNETEN ZUSTAND MIT EINEM SCHRAUBENZIEHER EINGESTELLT WERDEN.

OPTIONAL: IF THE ECCENTRIC LEVER IS TOO TIGHT OR TOO LOOSE, THE TENSION CAN BE ADJUSTED WITH A SCREWDRIVER WHEN IT IS OPEN.




3. IMPROVE ANTI-SCRATCH

UM KRATZER ZU VERMEIDEN, BENUTZE RAHMENSCHUTZFOLIE AN DEN KONTAKTSTELLEN (nicht beinhaltet)
TO AVOID SCRATCHES, USE ADHESIVE FRAME PROTECTION AT CONTACT POINTS (not included)




4. OPEN/CLOSE




QL2.2-SYSTEM


5. CHECK SECURE CLOSURE



6. LOWER HOOK







7. ADJUST LOWER HOOK TO TUBE SIZE



8. POSITION TOWARDS DIRECTION OF TRAVEL

OPTIONAL: SWITCH DIRECTION IF NEEDED

9. RETIGHTEN REGULARLY



ACCESSORIES

